

**CODE DESCRIPTION PKG**

**SWITCHES**

G001	6A. 1-Way Switch	20
G002	6A. 2-Way Switch	20
G003	6A. Bell Push	20
G004	6A. Indicator	20

**SOCKETS / FUSE**

G005	6A. 2 Pin Socket	20
G006	6A. 5 Pin Socket	10
G007	10A. Kitkat Fuse	10

**FAN DIMMER/REGULATOR**

G008	300W Electronic Dimmer	10
G009	Step Regulator (Switch Type)	10

**POWER SWITCHES / SOCKETS**

G010	16A. 1-Way Switch	10
G011	16A. 2-Way Switch	10
G012	6&16A. Multi Socket	10

**POWER COMBINED**

G013	6&16A. Switch Socket Combined	05
G014	6&16A. Switch Socket Combined with Box	05

**POWER 5 IN 1**

G015	6&16A. 5-In-One	05
G016	6&16A. 5-In-One with Box	05

