

CODE	DESCRIPTION	PKG
<b>VX SWITCHES</b>		
i001	6A. 1-Way Switch	20
i002	6A. 2-Way Switch	20
i003	6A. Bell Push	20
i004	6A. Indicator	20
<b>LX SWITCHES</b>		
i005	6A. 1-Way Switch	20
i006	6A. 2-Way Switch	20
i007	6A. Bell Push	20
i008	6A. Indicator	20
<b>SOCKETS / FUSE</b>		
i009	6A. 2 Pin Socket	20
i010	6A. 5 Pin Socket (Covered Back)	10
i011	10A. Kit Kat Fuse	10
<b>FAN DIMMER/REGULATOR</b>		
i012	300W Electronic Dimmer	10
i013	Step Regulator (Switch Type)	10
i014	Step Regulator (Socket Type)	10
<b>POWER SWITCHES / SOCKETS</b>		
i015	16A. 1-Way Switch	10
i016	16A. 2-Way Switch	10
i017	6&16A. Multi Socket	10
<b>POWER COMBINED</b>		
i018	6&16A. Switch Socket Combined with Indicator	05
i019	6&16A. Switch Socket Combined with Box with Indicator	05
<b>POWER 5 IN 1</b>		
i020	6&16A. 5-In-One	05
i021	6&16A. 5-In-One with Box	05

