



Pearl White



Pebble Grey



Midnight Black

MODULAR PLATE (WITH CHROME)

CODE	T051	T052	T053	T054	T055	T056	T057	T058	T059
MODULE	1 M	2 M	3 M	4 M	6 M	8 M HZ	8 M SQ	12 M	18 M
SIZE	3"x3"	3"x3"	4"x3"	5"x3"	8"x3"	10"x3"	5"x5"	8"x6"	8"x9"
PKG	10	10	10	10	10	10	10	10	10



CODE DESCRIPTION MODULE PKG

GEM SWITCHES

T026	10A 1 Way Switch	1	20
T027	10A 2 Way Switch	1	20
T028	10A Bell Push	1	20
T029	20A 1 Way Switch	1	20
T030	20A 2 Way Switch	1	20

ARCH SWITCHES

T031	10A 1 Way Switch	1	20
T032	10A 2 Way Switch	1	20
T033	10A Bell Push	1	20
T034	20A 1 Way Switch	1	20
T035	20A 2 Way Switch	1	20

2 MODULE SWITCHES

T036	20A 1-Way Switch With Indicator	2	10
T037	10A Bell Push With Indicator	2	10

SOCKETS

T038	2 Pin Socket with Safety Shutter	1	20
T039	6A 5 Pin Socket With Safety Shutter	2	10
T040	6 & 16A Multi Socket With Safety Shutter	2	10
T041	13A Multi Socket	2	10

ACCESSORIES

T042	Blank Plate	1	60
T043	Indicator	1	20
T044	Cable T.V. Socket	1	20
T045	Tel. Jack (2-Line)	1	20
T046	USB Socket	1	10

ELECTRONIC REGULATOR & MCB'S

T047	Step Regulator	1	10
T048	Step Regulator	2	10
T049	6-32A. MCB (SP)	1	10
T050	6-32A. MCB (DP)	2	10



CODE DESCRIPTION MODULE PKG

GEM SWITCHES

T001	10A 1 Way Switch	1	20
T002	10A 2 Way Switch	1	20
T003	10A Bell Push	1	20
T004	20A 1 Way Switch	1	20
T005	20A 2 Way Switch	1	20

ARCH SWITCHES

T006	10A 1 Way Switch	1	20
T007	10A 2 Way Switch	1	20
T008	10A Bell Push	1	20
T009	20A 1 Way Switch	1	20
T010	20A 2 Way Switch	1	20

2 MODULE SWITCHES

T011	20A 1-Way Switch With Indicator	2	10
T012	10A Bell Push With Indicator	2	10

SOCKETS

T013	2 Pin Socket with Safety Shutter	1	20
T014	6A 5 Pin Socket With Safety Shutter	2	10
T015	6 & 16A Multi Socket With Safety Shutter	2	10
T016	13A Multi Socket	2	10

ACCESSORIES

T017	Blank Plate	1	60
T018	Indicator	1	20
T019	Cable T.V. Socket	1	20
T020	Tel. Jack (2-Line)	1	20
T021	USB Socket	1	10

ELECTRONIC REGULATOR & MCB'S

T022	Step Regulator	1	10
T023	Step Regulator	2	10
T024	6-32A. MCB (SP)	1	10
T025	6-32A. MCB (DP)	2	10

